



# CNP Series 1/16-1/8 DIN CONTROLLER

INSTRUCTION SHEET

M5438/0914

Shop online at: [www.omega.com](http://www.omega.com) e-mail: [info@omega.com](mailto:info@omega.com)  
For latest product manuals: [www.omegamannual.info](http://www.omegamannual.info)

Made In United Kingdom



### Servicing North America:

U.S.A.: Omega Engineering, Inc., One Omega Drive, P.O. Box 4047  
Stamford, CT 06907-0047 USA  
Toll-Free: 1-800-826-6342 (USA & Canada only)  
Customer Service: 1-800-622-2378 (USA & Canada only)  
Engineering Service: 1-800-872-9436 (USA & Canada only)  
Tel: (203) 359-1660 Fax: (203) 359-770  
e-mail: [info@omega.com](mailto:info@omega.com)

For Other Locations Visit [omega.com/worldwide](http://omega.com/worldwide)

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.  
**WARNING:** These products are not designed for use in, and should not be used for, human applications.

### WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion, or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

### RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.  
© Copyright 2014 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

## 1/16 - 1/8 DIN CONTROLLER CONCISE PRODUCT MANUAL


**CAUTION:** Installation should be only performed by technically competent personnel. Local Regulations regarding electrical installation & safety must be observed.

### 1. INSTALLATION

The models covered by this manual have two different DIN case sizes (refer to section 10). Some installation details vary between models. These differences have been clearly shown.

**Note:** The functions described in sections 2 thru 9 are common to all models.

#### Installing Option Modules




To access modules 1, A or B, first detach the PSU and CPU boards from the front by lifting first the upper, and then lower mounting struts. Gently separate the boards.

- a. Plug the required option modules into the correct connectors, as shown below.
- b. Locate the module tongues in the corresponding slot on the opposite board.
- c. Hold the main boards together while relocating back on the mounting struts.
- d. Replace the instrument by aligning the CPU and PSU boards with their guides in the housing, then slowly push the instrument back into position.

**Note:** Option modules are automatically detected at power up.

#### Option Module Connectors



#### Panel-Mounting


The mounting panel must be rigid, and may be up to 6.0mm (0.25inch) thick. Cut-out sizes are:

- Cut-Out Dim A  
1/16 & 1/8 Din = 45mm
- Cut-Out Dim B  
1/16 Din = 45mm  
1/8 Din = 92mm



For n multiple instruments mounted side-by-side, cut-out A is 48n-4mm.

Tolerance +0.5, -0.0mm




**CAUTION:** For an effective IP66 seal against dust and moisture, ensure gasket is well compressed against the panel, with the 4 tongues located in the same ratchet slot.

#### Rear Terminal Wiring

USE COPPER CONDUCTORS (EXCEPT FOR T/C INPUT)

Single Strand wire gauge: Max 1.2mm (18SWG)



These diagrams show all possible option combinations. The actual connections required depends on the exact model and options fitted.

**CAUTION:** Check information label on housing for correct operating voltage before connecting supply to Power Input  
Fuse: 100 – 240V ac – 1amp anti-surge  
24/48V ac/dc – 315mA anti-surge

**Note:** At first power-up the message `Go to Conf` is displayed, as described in section 8 of this manual. Access to other menus is denied until configuration mode is completed

### 2. OPERATOR MODE

This mode is entered at power on, or accessed from Select mode (see section 2).

**Note:** All Configuration mode and Setup mode parameters must be set as required before starting normal operations.

Press **Left Arrow** to scroll through the parameters, then press **Up Arrow** or **Down Arrow** to set the required value.

**Note:** All Operator Mode parameters in Display strategy 6 are read only (see d 1SP in configuration mode), they can only be adjusted via Setup mode.

Upper Display	Lower Display	Display Strategy and When Visible	Description
PV Value	Active SP Value	1 & 2 (initial screen)	PV and target value of selected SP Local Setpoints are adjustable in Strategy 2
PV Value	Actual SP Value	3 & 6 (initial screen)	PV and actual value of selected SP (e.g. ramping SP value). Read only
PV Value	(Blank)	4 (initial screen)	Process variable only Read only
Active SP Value	(Blank)	5 (initial screen)	Target value of selected setpoint only. Read only
SP Value	SP	1, 3, 4, 5 & 6	Target value of SP Adjustable except in Strategy 6
Actual SP Value	SPrP	P is not blank	Actual (ramping) value of selected SP. Read only
Ramp Rate	rP	SPr enabled in Setup mode	SP ramping rate, in units per hour Adjustable except in Strategy 6
Active Alarm Status	ALSt	When one or more alarms are active. LOW BAND indicator will also flash	Alarm 2 active Alarm 1 active Loop Alarm active

#### Operating Mode Selection

Press **Up Arrow**, then press **Left Arrow** or **Right Arrow** to select operating mode.

Ctrl	OFF	Control and alarms off
	Auto	Controller in Automatic mode
	Man	Controller in Manual mode

#### Manual Control

While in Manual Control mode, the **LOW** and **BAND** indicators will flash and the lower display will show Pxxx (where xxx is the current manual power level). Switching to/from manual mode is via Bumpless Transfer. Press **Left Arrow** or **Right Arrow** to set the required output power.

**Caution:** Manual power level is not restricted by the OPuL power limit.

### 3. SELECT MODE

Select mode is used to access the configuration and operation menu functions.

It can be accessed at any time by holding down **Left Arrow** and pressing **Up Arrow**.

In select mode, press **Left Arrow** or **Right Arrow** to choose the required mode, press **Enter** to enter. An unlock code is required to prevent unauthorised entry to Configuration, & Setup modes. Press **Left Arrow** or **Right Arrow** to enter the unlock code, then press **Enter** to proceed.

Mode	Upper Display	Lower Display	Description	Default Unlock Codes
Operator	OPtr	SLCt	Normal operation	None
Set Up	SEtP	SLCt	Tailor settings to the application	44
Configuration	ConF	SLCt	Configure the instrument for use	44
Product Info	inFo	SLCt	Check manufacturing information	None
Auto-Tuning	Autun	SLCt	Invoke Pre-Tune or Self-Tune	44

**Note:** The instrument will always return automatically to Operator mode if there is no key activity for 2 minutes.

### 4. CONFIGURATION MODE

First select Configuration mode from Select mode (refer to section 2).

Press **Left Arrow** to scroll through the parameters, then press **Left Arrow** or **Right Arrow** to set the required value. Press **Enter** to accept the change, otherwise parameter will revert to previous value. To exit from Configuration mode, hold down **Left Arrow** and press **Left Arrow** to return to Select mode.

**Note:** Parameters displayed depends on how instrument has been configured. Refer to user guide (available from your supplier) for further details. Parameters marked \* are repeated in Setup Mode.

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value
Function	Func	HEAT	Heat Only	HEAT
		COOL	Heat/Cool	
		INDIC	Indicator Only	
Input Range/Type	inPt		See following table for possible codes	uL

Code	Input Type & Range	Code	Input Type & Range	Code	Input Type & Range
------	--------------------	------	--------------------	------	--------------------

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value
BC	B: 100 - 1824 °C	LC	L: 0.0 - 537.7 °C	2.4 FP PIRh20% vs 40%: 32 - 3362 °F
BF	B: 211 - 3315 °F	LF	L: 32.0 - 999.9 °F	
CC	C: 0 - 2320 °C	NC	N: 0 - 1399 °C	P TC Pt100: -199 - 800 °C
CF	C: 32 - 4208 °F	NF	N: 32 - 2551 °F	
JC	J: -200 - 1200 °C	RC	R: 0 - 1759 °C	P TC Pt100: -128.3 - 537.7 °C
JF	J: -328 - 2192 °F	RF	R: 32 - 3198 °F	
JLC	J: -128.8 - 537.7 °C	SC	S: 0 - 1762 °C	0_20 0 - 20 mA DC
JLF	J: -199.9 - 999.9 °F	SF	S: 32 - 3204 °F	
KC	K: -240 - 1373 °C	TC	T: -240 - 400 °C	0_50 0 - 50 mV DC
KF	K: -400 - 2503 °F	TF	T: -400 - 752 °F	
KLC	K: -128.8 - 537.7 °C	TLC	T: -128.8 - 400.0 °C	0_5 0 - 5 V DC
KLF	K: -199.9 - 999.9 °F	TLF	T: -199.9 - 752.0 °F	
LC	L: 0 - 762 °C	P24C	PIRh20% vs. 40%: 0 - 850 °C	0_10 0 - 10 V DC
LF	L: 32 - 1403 °F		2_10 2 - 10 V DC	

Note: Decimal point shown in table indicates temperature resolution of 0.1°

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value	
Scale Range Upper Limit	rUL		Scale Range Lower Limit +100 to Range Maximum	Range max (Lin=1000)	
Scale Range Lower Limit	rLL		Range Minimum to Scale Range Upper Limit -100	Range min (Linear=0)	
Decimal point position	dPo5		0=XXXX, 1=XXX.X, 2=XX.XX, 3=X.XXX (non-temperature ranges only)	1	
Primary Output Control Action	Ctrl	rEu	Reverse Acting	rEu	
		dIr	Direct Acting		
Alarm 1 Type	RLA1	P_Hi	Process High Alarm	Controller P_lo Indicator P_Hi	
		P_Lo	Process Low Alarm		
		dE	Deviation Alarm		
		bAnd	Band Alarm		
		nonE	No alarm		
High Alarm 1 value*	PhA1		Range Minimum to Range Maximum in display units	300	
Low Alarm 1 value*	PLA1			130	
Band Alarm 1 value*	bAL1		1 LSD to span from setpoint in display units	5	
Dev. Alarm 1 value*	dAL1		+/- Span from setpoint in display units	5	
Alarm 1 Hysteresis*	AHY1		1 LSD to full span in display units	1	
Alarm 2 Type*	RLA2		Options as for alarm 1	Controller bAnd Indicator nonE	
High Alarm 2 value*	PhA2				Range Max
Low Alarm 2 value*	PLA2			Range Min	
Band Alarm 2 value*	bAL2			10	
Dev. Alarm 2 value*	dAL2			5	
Alarm 2 Hysteresis*	AHY2			1	
Loop Alarm	LAEn		d,SA (disabled) or EnAb (enabled)	EnAb	
Loop Alarm Time*	LAEt		1 sec to 99 mins. 59secs	99.59	
Alarm Inhibit	Inh	nonE	No alarms Inhibited	nonE	
		ALA1	Alarm 1 inhibited		
		ALA2	Alarm 2 inhibited		
		both	Alarm 1 and alarm 2 inhibited		
Output 1 Usage	USE1	Pr	Primary Power	Pr	
		SEc	Secondary Power		
		Al_d	Alarm 1, Direct		
		Al_r	Alarm 1, Reverse		
		A2_d	Alarm 2, Direct		
		A2_r	Alarm 2, Reverse		
		LP_d	Loop Alarm, Direct		
		LP_r	Loop Alarm, Reverse		
		Or_d	Logical Alarm 1 OR 2, Direct		
		Or_r	Logical Alarm 1 OR 2, Reverse		
		Ad_d	Logical Alarm 1 AND 2, Direct		
		Ad_r	Logical Alarm 1 AND 2, Reverse		
		AR_d	Alarm 1 OR 2 OR Sensor Break, Direct		
		AR_r	Alarm 1 OR 2 OR Sensor Break, Reverse		
Output 2 Usage	USE2		As for output 1		SEc or A2_d

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value
Output 3 Usage	USE3		As for output 1	Controller AR_d Indicator A1_d
Display Strategy	d,SP		1, 2, 3, 4, 5 or 6 (refer to section 8)	1
Serial Communications Protocol	Prot	ASC I	ASCII	r7bn
		r7bn	Modbus with no parity	
		r7bE	Modbus with Even Parity	
		r7bo	Modbus with Odd Parity	
Serial Communications Bit Rate	bAud	1.2	1.2 kbps	9.6
		2.4	2.4 kbps	
		4.8	4.8 kbps	
		9.6	9.6 kbps	
		19.2	19.2 kbps	
Comms Address	Addr	1	1 to 255 (Modbus), 1 to 99 (ASCII)	1
Comms Write	CoEn	r_wJ	Read/Write	r_wJ
Configuration Lock Code	CLoc	r_0	Read only	r_0
			0 to 9999	0

## 5. SETUP MODE

Note: Configuration must be completed before adjusting Setup parameters.

First select Setup mode from Select mode (refer to section 2). Press  $\leftarrow$  to scroll through the parameters, then press  $\Delta$  or  $\nabla$  to set the required value.

To exit from Setup mode, hold down  $\leftarrow$  and press  $\Delta$  to return to Select mode.

Note: Parameters displayed depend on how instrument has been configured.

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value
Input Filter Time Constant	F ILt		OFF or 0.5 to 100.0 secs	2.0
Process Variable Offset	OFFS		±Span of controller	0
Primary Power	PPUJ		Current power levels (read only)	N/A
Secondary Power	SPUJ			
Primary Proportional Band	Pb_P		0.0% (ON/OFF) and 0.5% to 999.9% of input span	0.50
Secondary Proportional Band	Pb_S			5.50
Automatic Reset (Integral Time)	RrSt		1 sec to 99 mins 59 secs and OFF	20.00
Rate (Derivative Time)	rRtE		00 secs to 99 mins 59 secs	5.00
Overlap/Deadband	DL		-20 to +20% of Primary and Secondary Proportional Band	0
Manual Reset (Bias)	b,AS		0% (-100% if dual control) to 100%	25
Primary ON/OFF Differential	d,FP		0.1% to 10.0% of input span centered about the setpoint. (Entered as a percentage of span)	0.5
Secondary ON/OFF Diff.	d,FS			
Prim. & Sec. ON/OFF Differential	d,FF			
Setpoint Upper Limit	SPuL		Current Setpoint to Range max	R/max
Setpoint Lower limit	SPLL		Range min to Current Setpoint	R/min
Primary Output Power Limit	OPuL		0% to 100% of full power	100
Output 1 Cycle Time	Ct1		0.5, 1, 2, 4, 8, 16, 32, 64, 128, 256 or 512 secs.	4
Output 2 Cycle Time	Ct2			4
High Alarm 1 value	PhA1		Range Minimum to Range Maximum	300
Low Alarm 1 value	PLA1			130
Deviation Alarm 1 Value	dAL1		±Span from SP in display units	5
Band Alarm 1 value	bAL1		1 LSD to span from setpoint	5
Alarm 1 Hysteresis	AHY1		1 LSD to full span in display units	1
High Alarm 2 value	PhA2		Range Minimum to Range Maximum	R/max
Low Alarm 2 value	PLA2			R/min
Deviation Alarm 2 Value	dAL2		±Span from SP in display units	5
Band Alarm 2 value	bAL2		1 LSD to span from setpoint	5
Alarm 2 Hysteresis	AHY2		1 LSD to full span in display units	1
Loop Alarm Time	LAEt		1 LSD to full span in display units	99.59
Auto Pre-tune	APt		d,SA (disabled) or EnAb (enabled)	d,SA
Setpoint ramp adjustment shown in Operator Mode	SPr			

Parameter	Lower Display	Upper Display	Adjustment Range & Description	Default Value
SP Ramp Rate Value	rP		1 to 9999 units/hour or Off (blank)	Off
Setpoint Value	SP		Scale range upper to lower limits.	Scale Range Minimum
Setup Lock Code	SLoc		0 to 9999	44

## 6. AUTOMATIC TUNING MODE

First select Automatic tuning mode from Select mode (refer to section 2).

Press  $\leftarrow$  to scroll through the modes, then press  $\Delta$  or  $\nabla$  to set the required value.

To exit from Automatic tuning mode, hold down  $\leftarrow$  and press  $\Delta$ , to return to Select mode.

Pre-tune is a single-shot routine and is thus self-disengaging when complete.

If APt in Setup mode = EnAb, Pre-tune will attempt to run at every power up\*.

Parameter	Lower Display	Upper Display	Adjustment Range & Description	Default Value
Pre-Tune	Ptun		On or OFF. Indication remains OFF if automatic tuning cannot be used at this time*	OFF
Self-Tune	Stun			
Tune Lock	tLoc		0 to 9999	44

\* Note: Automatic tuning will not engage if either proportional band = 0.

Also, Pre-tune will not engage if setpoint is ramping, or the PV is less than 5% of input span from the setpoint.

## 7. PRODUCT INFORMATION MODE

First select Product information mode from Select mode (refer to section 2).

Press  $\leftarrow$  to view each parameter. To exit from Product Information mode,

hold down  $\leftarrow$  and press  $\Delta$  to return to Select mode.

Note: These parameters are all read only.

Parameter	Lower Display	Upper Display	Description
Input type	In_1	Un_1	Universal input
Option 1 module type fitted	OPn1	nonE	No option fitted
		rLY	Relay output
		SSr	SSR drive output
		tr_1	Triac output
Option 2 module type fitted	OPn2		As Option 1
Option 3 module type fitted	OPn3	nonE	No option fitted
		rLY	Relay output
		SSr	SSR drive output
Auxiliary Option A Module type fitted	OPnA	nonE	No option fitted
		r485	RS485 communications
Firmware Type	FLW		Value displayed is firmware type number
Firmware Issue	ISS		Value displayed is firmware issue number
Product Revision Level	PrL		Value displayed is Product Revision level
Date of manufacture	d0r7		Manufacturing date code (mmyy)
Serial number 1	Sn1		First four digits of serial number
Serial number 2	Sn2		Middle four digits of serial number
Serial number 3	Sn3		Last four digits of serial number

## 8. MESSAGES & ERROR INDICATIONS

These messages indicate that an error has occurred or there is a problem with the process variable signal or its wiring.

Caution: Do not continue with the process until the issue is resolved.

Parameter	Upper Display	Lower Display	Description
Instrument parameters are in default conditions	Goto	Conf	Configuration & Setup required. This screen is seen at first turn on, or if hardware configuration has been changed. Press $\leftarrow$ to enter the Configuration Mode, next press $\Delta$ or $\nabla$ to enter the unlock code number, then press $\leftarrow$ to proceed
Input Over Range	[HH]	Normal	Process variable input > 5% over-range
Input Under Range	[LL]	Normal	Process variable input > 5% under-range
Input Sensor Break	OPEN	Normal	Break detected in process variable input sensor or wiring
RSP Over Range	Normal	[HH]**	RSP input over-range
RSP Under Range	Normal	[LL]**	RSP input under-range
RSP Break	Normal	OPEN**	Break detected in RSP input signal
Option 1 Error	Err	OPn1	Option 1 module fault
Option 2 Error		OPn2	Option 2 module fault

Option 3 Error		OPn3	Option 3 module fault
Option A Error		OPnA	Option A module fault or RSP in both A & B
Option B Error		OPnB	Option B module fault

## 9. SERIAL COMMUNICATIONS

Refer to the Modbus Communications User Manual (Available from your supplier) for details.

## 10. SPECIFICATIONS

### UNIVERSAL INPUT

Thermocouple: ±0.1% of full range, ±1LSD (±1°C for Thermocouple CJC). Calibration: BS4937, NBS125 & IEC584.

PT100 Calibration: ±0.1% of full range, ±1LSD. BS1904 & DIN43760 (0.00385Ω/Ω°C).

DC Calibration: ±0.1% of full range, ±1LSD.

Sampling Rate: 4 per second.

Impedance: >10MΩ resistive, except DC mA (5Ω) and V (47kΩ).

Sensor Break Detection: Thermocouple, RTD, 4 to 20 mA, 2 to 10V and 1 to 5V ranges only. Control outputs turn off.

Isolation: Isolated from all outputs (except SSR driver).

Universal input must not be connected to operator accessible circuits if relay outputs are connected to a hazardous voltage source. Supplementary insulation or input grounding would then be required.

### OUTPUTS

#### Relay

Contact Type & Rating: Single pole double throw (SPDT); 2A resistive at 120/240VAC.

Lifetime: >500,000 operations at rated voltage/current.

Isolation: Basic Isolation from universal input and SSR outputs.

#### SSR Driver

Drive Capability: SSR drive voltage >10V into 500Ω min.

Isolation: Not isolated from universal input or other SSR driver outputs.

#### Triac

Operating Voltage: 20 to 280Vrms (47 to 63Hz).

Current Rating: 0.01 to 1A (full cycle rms on-state @ 25°C); derates linearly above 40°C to 0.5A @ 80°C.

Isolation: Reinforced safety isolation from inputs and other outputs.

### SERIAL COMMUNICATIONS

Physical: RS485, at 1200, 2400, 4800, 9600 or 19200 bps.

Protocols: Selectable between Modbus and West ASCII.

Isolation: Reinforced safety isolation from all inputs and outputs.

### OPERATING CONDITIONS (FOR INDOOR USE)

Ambient Temperature: 0°C to 55°C (Operating), -20°C to 80°C (Storage).

Relative Humidity: 20% to 95% non-condensing.

Altitude: <2000m

Supply Voltage and Power: 100 to 240VAC ±10%, 50/60Hz, 7.5VA (for mains powered versions), or 20 to 48VAC 50/60Hz 7.5VA or 22 to 65VDC 5W (for low voltage versions).

### ENVIRONMENTAL

Standards: CE, UL, ULC, CSA

EMI: Complies with EN61326 (Susceptibility & Emissions).

Safety Considerations: Complies with EN61010-1, UL61010-1 & CSA 22.2 No 1010.1 92

Panel Sealing: Front to IP66 when correctly mounted – refer to section 1. Rear of panel to IP20.

### PHYSICAL

Front Bezel Size: 1/16 Din = 48 x 48mm, 1/8 Din = 96 x 48mm.

Depth Behind Panel: 1/16 Din = 110mm, 1/8 Din = 100mm.

Weight: 0.21kg maximum.

### SUPPLEMENTARY INFORMATION FOR CSA

-Compliance shall not be impaired when fitted to the final installation.

-Designed to offer a minimum of Basic Insulation only.

-The body responsible for the installation is to ensure that supplementary insulation suitable for Installation Category II is achieved when fully installed.

-To avoid possible hazards, accessible conductive parts of the final installation should be protectively earthed in accordance with EN6010 for Class 1 Equipment.

-Output wiring should be within a Protectively Earthed cabinet.

Sensor sheaths should be bonded to protective earth or not be accessible.

-Live parts should not be accessible without the use of a tool.

-When fitted to the final installation, an IEC/CSA APPROVED disconnecting device should be used to disconnect both LINE and NEUTRAL conductors simultaneously.

-A clear instruction shall be provided not to position the equipment so that it is difficult to operate the disconnecting device.