

**5 YEAR**  
WARRANTY



OM-ES-511



OM-ES-522



# OMEGA® User's Guide

Shop online at  
[omega.com](http://omega.com)®

e-mail: [info@omega.com](mailto:info@omega.com)

For latest product manuals:  
[omegamanual.info](http://omegamanual.info)

**ISO 9001**  
CERTIFIED  
CORPORATE QUALITY

STAMFORD, CT

**ISO 9001**  
CERTIFIED  
CORPORATE QUALITY

MANCHESTER, UK

# OM-ES-500 SERIES Industrial Ethernet-to-Serial Device Servers



OMEGAnet® Online Service  
omega.com

Internet e-mail  
info@omega.com

### Servicing North America:

U.S.A.:  
ISO 9001 Certified

Omega Engineering Inc., One Omega Drive, P.O.Box 4047  
Stamford, CT 06907-0047 USA  
Toll-Free: 1-800-826-6342  
FAX: (203) 359-7700

TEL: (203) 359-1600  
e-mail: info@omega.com

Canada:

976 Bergar, Laval (Quebec) H7L 5A1, Canada  
Toll-Free: 1-800-826-6342  
FAX: (514) 856-6886

TEL: (514) 856-6928  
e-mail: info@omega.com

### For immediate technical or application assistance:

U.S.A. and Canada:

Sales Service: 1-800-826-6342/1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378/1-800-622-BEST™  
Engineering Service: 1-800-872-9436/1-800-USA-WHEN™

Mexico/  
Latin America:

TEL: 001 (203) 359-1660  
e-mail: espanol@omega.com

FAX: 001 (203) 359-7700

### Servicing China:

China:

1698 Yi Shan Road, Unit 102, Min Hang District, Shanghai, China 201103 P.R.C.  
Hotline: 800 819 0559/400 619 0559,

e-mail: info@cn.omega.com

### Servicing Europe:

Benelux:

Toll-Free: 0800 099 3344  
FAX: +31 20 643 46 43

TEL: +31 20 347 21 21  
e-mail: sales@omegaeng.nl

Czech Republic:

Frystatska 184, 733 01 Karviná, Czech Republic  
TEL: +420-59-6311899  
e-mail: info@omegashop.cz

FAX: +420-59-6311114

France:

Toll-Free: 0805 541 038  
FAX: 01 57 32 48 18

TEL: +1 57 32 48 17  
e-mail: esales@omega.fr

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
Toll-Free: 0800 8266342  
FAX: +49 (0) 7056 9398-29

TEL: +49 (0) 7056 9398-0  
e-mail: info@omega.de

United Kingdom:

ISO 9001 Certified

OMEGA Engineering, Ltd., One Omega Drive, River Bend Technology Centre  
Northbank, Irlam, Manchester M44 5BD United Kingdom  
Toll-Free: 0800-488-488  
FAX: +44 (0) 161 777-6622

TEL: +44 (0) 161 777-6611  
e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used, for human applications.

# Contents

1. Box Contents Check List	4
2. Hardware	5
3. Network IP Addressing	6
4. Connecting your OM-ES-500 Series Device	7
5. Installing your OM-ES-500 Series Device on Windows	8
6. Configuring your OM-ES-500 Series Device	10
7. Default Settings	12
8. Pin outs	13
9. LED information	14

For more information, please refer to Product Manual on CD

Information on Product Accreditations, Safety, and correct disposal of this product can be found on the Product CD

# 1. Box Contents Check List

Thank you for purchasing an OM-ES-500 Series Ethernet to Serial product. This quick start guide will help you set up your ES device so that you can begin experiencing the benefits of Ethernet to Serial technology.



Ethernet to Serial  
Device




Quick Start Guide



Product CD

NB: Image shown is an OM-ES-522 1x RS232/422/485 and is an example. The same steps can be applied to all other products in the OM-ES-500 Series

## 2. Hardware



1.	Port 1 - Yellow removable screw terminal block	6.	Ethernet Port LED
2.	Port 2 - Grey removable screw terminal block (OM-ES-522)	7.	Status LED
3.	Power Input - Black removable screw terminal block +5VDC to +30VDC	8.	Reset button (use unfolded paperclip to press)
4.	Ethernet port connection - 10BaseT / 100BaseTX	9.	IP-30 rated non-conducting polyamide case
5.	Serial Port(s) LED	10.	DIN Rail mount
		11.	Earth to DIN rail
		12.	Ventilation

### 3. Network IP Addressing

The OM-ES-500 Series device is shipped in “DHCP Mode”.

- On connecting to the network, the device automatically checks if it is connected to a DHCP Server. If this is the case, the DHCP server will allocate an IP address automatically to the OM-ES-500 Series device.
- If no DHCP Server is detected (e.g. you are using a direct cable connection to the PC), the OM-ES-500 Series device will default to an IP address of 192.168.127.254 within 60 seconds.

Please ensure the PC you're using for configuration can communicate with the 192.168.127.xxx IP range.

## 4. Connecting your OM-ES-500 Series Device

1. Connect the OM-ES-500 Series device to your local network or use a direct cable connection using a standard straight-through or crossover Ethernet cable and plugging into the Ethernet port connection.
2. Connecting to Power: Connect the power adapter or a DC power line (+5 to +30VDC) to the OM-ES-500 Series power terminal block or jack connection. If using your own power supply please check input requirements on page 5 - Hardware.

The OM-ES-500 Series devices feature dual power supply inputs, only one power supply need be connected to ensure the device is powered up and working.

3. Confirm the device beeps as it is turned on.
4. When the Status LED turns steady green (after 5-60 seconds), the device is ready to use.
5. Connect the serial cable from your serial device to the serial port on the OM-ES-500 Series device. Refer to Section 8 of this Quick Start Guide for pin outs.

**Make a note of device MAC address (on side panel, 00-0a-4f-XX-XX-XX) as you will need it to identify the device on your network later.**

## 5. Installing your OM-ES-500 Series Device on Windows



1. Insert the CD into your PC. This should launch the Boost.LAN Navigation Page automatically.

Note: If the navigation page does not auto load, go to Start → My Computer → Right Click the CD and select Explore. Locate the “Setup.exe” program on the CD and double click to launch. If installing the software in Windows 2000 launch the “SetupW2k.exe” program on the CD.

2. Click “Install” to launch the Boost.LAN Setup.exe

3. Follow the on screen instructions to install the Boost.LAN software.

Note: Boost.LAN software requires the Microsoft .NET framework to be installed on your machine. If it is not already installed, the Setup.exe will install it automatically. Please follow on screen instructions and reboot if prompted to continue installation.




4. When installation is complete, you should see an icon labelled Boost.LAN Manager on the desktop. Double click the link to open the application

## 5. Installing your OM-ES-500 Series Device Continued...

- Click on the “File -> Find Devices” button in the top left hand side of the window.



- You can find your Omega OM-ES-500 Series device by selecting a device and matching it with the corresponding MAC address available on the left hand panel.
- Once found, select the device and scroll to the “Tasks” section on the left hand panel
- Click Install Device.
- When the device is installed a pop up box will appear saying “Your new hardware is installed and ready to use.”



## 6. Configuring your OM-ES-500 Series Device

### Changing Port Type

ES Industrial devices can operate either as:

- RS232
- RS422 Full Duplex mode with 2 twisted pairs or RS485 Full Duplex using 2 pairs of wire.
- RS485 Half Duplex autogating mode using on 1 pair of wires

By default the OM-ES-500 Series device port type is set to RS232. The port type can be changed on the Serial Port pages of the web configuration page. To get to the web configuration page, type the IP address of your device into a web browser.

The screenshot shows the 'Serial Port 1' configuration interface. At the top, the 'Port Status' is 'Idle'. The 'Port Type' is currently set to 'RS232'. Below this, there are two additional options: 'RS422/485' and 'RS422/485'. A note indicates that the selected port type must be set or removed according to the manual. Under the 'Default Port Settings' section, there is a checkbox for 'Always use these settings (Ignore settings from application)'. The 'Baud Rate' is set to '115200' bps. The 'Data Bits' are set to '8', 'Parity' is set to 'None', and 'Stop Bits' are set to '1'. 'Flow Control' is set to 'None'.

When the RS422/485 port type is selected an additional drop down box appears allowing the user to set the duplex mode.

- Select “RS422 full-duplex mode” for RS422 or RS485 Full Duplex communications.
- Select “RS485 half-duplex autogating mode” for RS485 Half Duplex communications.

When setting RS422 or RS485 mode, as well as configuring the software, the case of the OM-ES-500 Series device needs opening and

## 6. Configuring your OM-ES-500 Series Device Continued...

the hardware needs configuring by setting the jumpers inside. For more detailed information on configuring your Ethernet to Serial device, including the hardware jumper configuration, please see the product manual on the CD which came with your ES device.

### Firewall Exceptions and Port Numbers

When using the OM-ES-500 Series devices with a firewall you may need to manually add the exception entries and port numbers to the firewall list. Listed below are the default port numbers and the firewall exceptions.

Program Name	Default Port Number
Device Web Server	80
Serial Port 1	9001
Serial Port 2	9002
Firmware Upgrade	67 (BOOTP Server) 68 (BOOTP Client) 69 (TFTP Port)

Default Windows Firewall Exception entries:

- Boost.LAN Suite
- Boost.LAN Suite (Device discovery) (except Windows XP 32 & 64 bits)
- UPnP Framework (Windows XP 32 & 64 bits)
- Network Discovery (Windows 7 or later)

## 7. Default Settings

Network Settings		
Device Network Address	DHCP mode	
Web Server Port	80	
Port Settings	RS232	RS422/485
Baudrate	115200	115200
Databits	8	8
Stop Bits	n	n
Parity	1	1
Flow Control	None	None
Duplex Mode	N/A	Full Duplex
Protocol Settings	Telnet Mode (Server)	Telnet Mode (Server)
TCP/UDP Port Numbers		
Device Web Server	80 (TCP)	
Serial Ports 1-8	9001-9008 (TCP)	
Firmware Upgrade	67 (UDP) - BOOTP Server 68 (UDP) - BOOTP Client 69 (UDP) - TFTP Port	

## 8. Pin Outs

Port 1 - Yellow	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5
RS232	Sig GND	CTS	RxD	RTS	TxD
RS485 FD	Sig GND	RxD-	RxD+	TxD+	TxD-
RS485 HD	Sig GND			Data+	Data-
Power Input - Black	Power GND	+Vin A	+Vin B	Power GND	Func GND
Input	+5V to +30V DC 60mA@24V 1.4W Typical			120mA@24V 2.9W Max	

Ports 1 and 2 are software selectable as either RS232, RS422 or RS485:

- Port 1 terminal = yellow
- Port 2 terminal = grey
- Power terminal = black

Grounding:

- Correctly Wired grounds help cut down on electromagnetic radiation
- 5 pin terminals allow a ground on the 5th pin of each block
- Functional earth included in integral DIN rail mount allows the DIN rail to be used as an earth

## 9. LED Information

LED Information		
Status LED	Green Light on	Device Ready
	Flashing Yellow	Changing Settings
	Flashing between Red & Green	Querying IP
	Flashing between Green & Red/Yellow	IP Address Diagnostic
	Flashing Green/Red	Performing Hard Reset
	Flashing between Green & Yellow	Initialization diagnostic
Serial Port LED	Green light on	Port Open
	Flashing light on	Data RX/TX
Ethernet LED	Green light on	Link established
	Flashing Green	Data RX/TX

For further configuration details, or technical information on the OM-ES-500 Series product, please refer to Product Manual on CD

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC., warrants this unit to be free of defects in materials and workmanship for a period of 61 months from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal five (5) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

**CONDITIONS:** Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence. The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA.

1. Purchase order number which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY RETURNS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA.

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords customers the latest technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© COPYRIGHT 2013 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, translated, or reduced to any electronic medium-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

# Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA... Of Course!**

Shop online at [omega.com](http://omega.com)<sup>SM</sup>

## **TEMPERATURE**

Thermocouple RTD & Thermister Probes  
Connectors, Panels & Assemblies  
Wire: Thermocouple, RTD & Thermister  
Calibrators & Ice Point References  
Recorders, Controllers & Process  
Monitors  
Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

Transducers & Strain Gages  
Load Cells & Pressure Gages  
Displacement Transducers  
Instrumentation & Accessories

## **FLOW/LEVEL**

Rotameters Gas Mass Flowmeters & Flow  
Computers  
Air Velocity Indicators  
Turbine/Paddlewheel Systems  
Totalizers & Batch Controllers

## **PH/CONDUCTIVITY**

pH Electrodes Testers & Accessories  
Benchtop/Laboratory Meters  
Controllers, Calibrators, Simulators &  
Pumps  
Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

Data Acquisition & Engineering Software  
Communications-Based Acquisition  
Systems  
Plug-in Cards for Apple, IBM, &  
Compatibles  
Data Logging Systems  
Recorders, Printers, & Plotters

## **HEATERS**

Heating Cable  
Cartridge & Strip Heaters  
Immersion & Band Heaters  
Flexible Heaters  
Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

Metering & Control Instrumentation  
Refractometers  
Pumps & Tubing  
Air, Soil & Water Monitors  
Industrial Water & Wastewater Treatment  
pH Conductivity & Dissolved Oxygen  
Instruments