



Spring loaded fitting for use with SLF-12-12-14 0.25" ½ NPT connection heads

C

Comes complete with installation instructions.

Notes: ¼-SLK: To install slide hex housing onto your probe with the ½ NPT threads pointed toward your thermowell or other suitable attachment point. Slide the self-gripping spring onto your probe with the wide end toward the hex housing and slide into place. Position of the assembly can be adjusted as needed.

SLF-12-12-14: To install the fitting onto your probe, slide the probe tip into the larger opening end of the fitting, twist the probe clockwise while pushing the probe through the fitting. Install the probe to the desired length, if needed the probe can be pulled through to re-adjust the position of the fitting.

Ordering Examples: ¼-SLK, includes hex housing with ½ NPT male thread and self gripping spring

SLF-12-12-14, fitting with ½ NPT male threads both ends with self gripping spring inside housing.